
WILDEN[®]

Engineering
Operation &
Maintenance

P420/P430 FIT Metal Pump



Where Innovation Flows

wildenpump.com

airpumping.co.uk





TABLE OF CONTENTS

SECTION 1	CAUTIONS—READ FIRST!
SECTION 2	WILDEN PUMP DESIGNATION SYSTEM2
SECTION 3	HOW IT WORKS—PUMP & AIR DISTRIBUTION SYSTEM
SECTION 4	DIMENSIONAL DRAWINGS4
SECTION 5	PERFORMANCE
	P420/P430 Metal Rubber-Fitted6P420/P430 Metal EZ-InstallTPE-Fitted6P420/P430 Metal Full-Stroke PTFE-Fitted7Suction-Lift Curves8
SECTION 6	SUGGESTED INSTALLATION, OPERATION & TROUBLESHOOTING10
SECTION 7	DISASSEMBLY / REASSEMBLY
SECTION 8	Air Valve / Center Section Disassembly
	P420/P430 Metal
SECTION 9	ELASTOMER OPTIONS22









CAUTIONS—READ FIRST!



CAUTION: Do not apply compressed air to the exhaust port — pump will not function.



CAUTION: Do not over-lubricate air supply excess lubrication will reduce pump performance. Pump is pre-lubed.



TEMPERATURE LIMITS:

Acetal	−29°C to 82°C	-20°F to 180°F
Buna-N	-12°C to 82°C	10°F to 180°F
Geolast®	–40°C to 82°C	–40°F to 180°F
Neoprene	–18°C to 93°C	0°F to 200°F
Nordel® EPDM	–51°C to 138°C	-60°F to 280°F
Nylon	–18°C to 93°C	0°F to 200°F
PFA	–7°C to 107°C	45°F to 225°F
Polypropylene	0°C to 79°C	32°F to 175°F
Polyurethane	−12°C to 66°C	10°F to 150°F
PVDF	-12°C to 107°C	10°F to 225°F
Saniflex™	–29°C to 104°C	-20°F to 220°F
SIPD PTFE with EPDM-backed	4°C to 137°C	40°F to 280°F
SIPD PTFE with Neoprene-backe	d 4°C to 93°C	40°F to 200°F
PTFE1	4°C to 104°C	40°F to 220°F
Viton® FKM	–40°C to 177°C	-40°F to 350°F
Wil-Flex [™]	–40°C to 107°C	–40°F to 225°F

¹4°C to 149°C (40°F to 300°F) - 13 mm (1/2") and 25 mm (1") models only.

NOTE: Not all materials are available for all models. Refer to Section 2 for material options for your pump.



CAUTION: When choosing pump materials, be sure to check the temperature limits for all wetted components. Example: Viton® has a maximum limit of 177°C (350°F) but polypropylene has a maximum limit of only 79°C (175°F).



CAUTION: Maximum temperature limits are based upon mechanical stress only. Certain chemicals will significantly reduce maximum safe operating temperatures. Consult the Chemical Resistance Guide for chemical compatibility and temperature limits.



WARNING: Prevent static sparking. If static sparking occurs, fire or explosion could result. Pump, valves and containers must be grounded to a proper grounding point when handling flammable fluids and whenever discharge of static electricity is a hazard.



CAUTION: Do not exceed 8.6 bar (125 psig) air supply pressure.



CAUTION: The process fluid and cleaning fluids $^{f \lambda}$ must be chemically compatible with all wetted pump components.



CAUTION: Do not exceed 82°C (180°F) air inlet temperature for Pro-Flo® models.



CAUTION: Pumps should be thoroughly flushed before installing into process lines. FDA- and USDA-approved pumps should be cleaned and/ or sanitized before being used.



CAUTION: Always wear safety glasses when operating pump. If diaphragm rupture occurs, material being pumped may be forced out air exhaust.



CAUTION: Before any maintenance or repair is attempted, the compressed air line to the pump should be disconnected and all air pressure allowed to bleed from pump. Disconnect all intake, discharge and air lines. Drain the pump by turning it upside down and allowing any fluid to flow into a suitable container.



CAUTION: Blow out air line for 10 to 20 seconds before attaching to pump to make sure all pipeline debris is clear. Use an in-line air filter. A 5µ (micron) air filter is recommended.



NOTE: When installing PTFE diaphragms, it is important to tighten outer pistons simultaneously (turning in opposite directions) to ensure tight fit. (See torque specifications in Section 7.)



NOTE: Some PTFE-fitted pumps come standard from the factory with expanded PTFE gaskets installed in the diaphragm bead of the liquid chamber. PTFE gaskets cannot be re-used.



NOTE: Before starting disassembly, mark a line from each liquid chamber to its corresponding air chamber. This line will assist in proper alignment during reassembly.



CAUTION: Pro-Flo® pumps cannot be used in submersible applications. Pro-Flo® SHIFT is available in both single-point exhaust (submersible) and standard (non-submersible) options. Do not use standard Pro-Flo® SHIFT models in submersible applications.



CAUTION: Tighten all hardware prior to installation.






WILDEN PUMP DESIGNATION SYSTEM

P420/P430 FIT METAL

38 mm (1-1/2") Pump **Maximum Flow Rate:** 492 lpm (130 gpm)



MATERIAL CODES

MODEL

P420 = PRO-FLO® THREADED

PORTS

P430 = PRO-FLO® FLANGED PORTS

WETTED PARTS/OUTER PISTON

AA = ALUMINUM/ALUMINUM

= STAINLESS STEEL/ STAINLESS STEEL

WM = DUCTILE IRON / MILD STEEL WS = DUCTILE IRON / STAINLESS

STEEL

WW= DUCTILE IRON / DUCTILE IRON

AIR CHAMBERS

= ALUMINUM

CENTER BLOCK

= POLYPROPYLENE

AIR VALVE

= POLYPROPYLENE

DIAPHRAGMS

BNS = BUNA-N (Red Dot)

EPS = EPDM (Blue Dot)

FWS = FULL-STROKE SANITARY WIL-FLEX™, EZ-INSTALL

[Santoprene® (Two Black Dots)] NES = NEOPRENE (Green Dot)

TEU = PTFE W/EPDM BACKUP

(White) TNU = PTFE W/NEOPRENE BACKUP

(White)

TSS = FULL-STROKE PTFE W/SANIFLEX™ BACK-UP

TSU = PTFE W/SANIFLEXTMBACKUP (White)

TWS = FULL-STROKE PTFE W/WIL-FLEX™ BACK-UP

VTS = VITON® (White Dot)

XBS = CONDUCTIVE BUNA-N (Two Red Dots)

ZGS = GEOLAST®, EZ-INSTALL (Black)

ZPS = POLYURETHANE, EZ-INSTALL (Clear)

ZSS = SANIFLEXTM, EZ-INSTALL [Hytrel® (Cream)]

WIL-FLEX™, EZ-INSTALL [Santoprene® (Three Black

Dots)]

VALVE BALLS

BN = BUNA-N (Red Dot)

= SANIFLEXTM [Hytrel® (Cream)] FS

EP = EPDM (Blue Dot) NE = NEOPRENE (Green Dot)

PU = POLYURETHANE (Brown)

TF = PTFE (White)

VT = VITON® (Silver or White Dot) WF = WIL-FLEXTM [Santoprene® (Three Black Dots)]

VALVE SEATS

A = ALUMINUM

BN = BUNA-N (Red Dot)

EP = EPDM (Blue Dot)

FS = SANIFLEXTM [Hytrel® (Cream)] FW = SANITARY WIL-FLEXTM

[Santoprene® (Two Black Dots)]

MILD STEEL

NEOPRENE (Green Dot) NE

PU= POLYURETHANE (Brown)

STAINLESS STEEL

VT = VITON® (White Dot)

WF = WIL-FLEX™ [Santoprene®

(Three Black Dots)]

VALVE SEAT O-RINGS

TF = PTFE

SPECIALTY CODES

0100 Wil-Gard 110V 0102 Wil-Gard sensor wires ONLY Wil-Gard 220V

Pump Cycle Monitor (sensor & wires)

Pump Cycle Monitor (module, sensor & wires) Pump Cycle Monitor (module, sensor & wires), DIN flange

0651 Vertically-Ported Discharge, NPT (1.25 in) 0652 Vertically-Ported Discharge, BSPT (1.25 in)

NOTE: Most elastomeric materials use colored dots for identification.


NOTE: Not all models are available with all material options.


Viton® is a registered trademark of DuPont Dow Elastomers.

PROFILO®

HOW IT WORKS—PUMP

The Wilden diaphragm pump is an air-operated, positive displacement, self-priming pump. These drawings show flow pattern through the pump upon its initial stroke. It is assumed the pump has no fluid in it prior to its initial stroke.





B toward the center of the pump creates

a vacuum within chamber B. Atmospheric

pressure forces fluid into the inlet

manifold forcing the inlet valve ball off its

seat. Liquid is free to move past the inlet valve ball and fill the liquid chamber (see




FIGURE 2 When the pressurized diaphragm, diaphragm A, reaches the limit of its discharge stroke, the air valve redirects pressurized air to the back side of diaphragm B. The pressurized air forces diaphragm B away from the center while pulling diaphragm A to the center. Diaphragm B is now on its discharge stroke. Diaphragm B forces the inlet valve ball onto its seat due to the hydraulic forces developed in the liquid chamber and manifold of the pump. These same hydraulic forces lift the discharge valve ball off its seat, while the opposite discharge valve ball is forced onto its seat, forcing fluid to flow through the pump discharge. The movement of diaphragm A toward the center of the pump creates a vacuum within liquid chamber A. Atmospheric pressure forces fluid into the inlet manifold of the pump. The inlet valve ball is forced off its seat allowing the fluid being pumped to fill the liquid chamber.





FIGURE 3 At completion of the stroke, the air valve again redirects air to the back side of diaphragm A, which starts diaphragm B on its exhaust stroke. As the pump reaches its original starting point, each diaphragm has gone through one exhaust and one discharge stroke. This constitutes one complete pumping cycle. The pump may take several cycles to completely prime depending on the conditions of the application.



shaded area).

HOW IT WORKS—AIR DISTRIBUTION SYSTEM





The Pro-Flo® patented air distribution system incorporates two moving parts: the air valve spool and the pilot spool. The heart of the system is the air valve spool and air valve. This valve design incorporates an unbalanced spool. The smaller end of the spool is pressurized continuously, while the large end is alternately pressurized then exhausted to move the spool. The spool directs pressurized air to one air chamber while exhausting the other. The air causes the main shaft/ diaphragm assembly to shift to one side — discharging liquid on that side and pulling liquid in on the other side. When the shaft reaches the end of its stroke, the inner piston actuates the pilot spool, which pressurizes and exhausts the large end of the air valve spool. The repositioning of the air valve spool routes the air to the other air chamber.




DIMENSIONAL DRAWINGS

P420 Metal









DIMENSIONS

ITEM	METRIC (mm)	STANDARD (inch)
Α	442	17.4
В	64	2.5
С	248	9.8
D	391	15.4
E	445	17.5
F	51	2.0
G	250	9.8
Н	93	3.7
J	132	5.2
K	292	11.5
L	384	15.1
M	274	10.8
N	224	8.8
Р	152	6.0
R	178	7.0
S	11	0.4

LW0375 REV. B

P420 Metal - Vertical





M N P R

DIMENSIONS

ITEM	METRIC (mm)	STANDARD (inch)
А	442	17.4
В	64	2.5
С	248	9.8
D	391	15.4
E	429	16.9
F	51	2.0
G	250	9.8
Н	93	3.7
J	132	5.2
K	292	11.5
L	384	15.1
M	274	10.8
N	224	8.8
Р	152	6.0
R	178	7.0
S	11	0.4


LW0376 REV. B





DIMENSIONAL DRAWINGS

P430 Aluminum




DIMENSIONS

ITEM	METRIC (mm)	STANDARD (inch)				
Α	442	17.4				
В	80	3.1				
С	311	12.3				
D	531	20.9				
Е	594	23.4				
F	606	23.9				
G	122	4.8				
Н	122	4.8				
J	93	3.7				
K	132	5.2				
L	293	11.5				
M	384	15.1				
N	313	12.3				
Р	247	9.7				
R	206	8.1				
S	152	6.0				
T	170	6.7				
U	11	0.4				
	DIN (mm)	ANSI (Inch)				
V	150 DIA.	5.0 DIA.				
W	109 DIA.	3.9 DIA.				
Х	18 DIA.	0.6 DIA.				

LW0377 REV. B

P430 Metal



DIMENSIONS

ITEM	METRIC (mm)	STANDARD (inch)
Α	443	17.5
В	89	3.5
С	273	10.8
D	528	20.8
Е	529	20.8
F	275	10.8
G	93	3.7
Н	84	3.3
J	86	3.4
K	132	5.2
L	292	11.5
M	384	15.1
N	274	10.8
Р	224	8.8
R	178	7.0
S	203	8.0
Т	11	0.4
	DIN (mm)	ANSI (Inch)
U	150 DIA.	5.0 DIA.
V	109 DIA.	4.3 DIA.
W	18 DIA.	0.6 DIA

LW0378 REV. C




PERFORMANCE

P420/P430 METAL RUBBER-FITTED

¹Displacement per stroke was calculated at 4.8 bar (70 psig) air inlet pressure against 2 bar (30 psig) head pressure.

Example: To pump 326 lpm (86 gpm) against a discharge head of 3.1 bar (30 psig) requires 5.5 bar (80 psig) and 101 Nm³/h (64 scfm) air consumption.


Caution: Do not exceed 8.6 bar (125 psig) air supply pressure.



Flow rates indicated on chart were determined by pumping water.

For optimum life and performance, pumps should be specified so that daily operation parameters will fall in the center of the pump's performance curve.


P420/P430 METAL **EZ-INSTALL TPE-FITTED**



¹Displacement per stroke was calculated at 4.8 bar (70 psig) air inlet pressure against 2 bar (30 psig) head pressure.

Example: To pump 193 lpm (51 gpm) against a discharge head of 4.1 bar (60 psig) requires 5.5 bar (80 psig) and 68 Nm³/h (43 scfm) air consumption.

Caution: Do not exceed 8.6 bar (125 psig) air supply pressure.



Flow rates indicated on chart were determined by pumping water.


For optimum life and performance, pumps should be specified so that daily operation parameters will fall in the center of the pump's performance curve.





PERFORMANCE


P420/P430 METAL REDUCED-STROKE PTFE-FITTED



¹Displacement per stroke was calculated at 4.8 bar (70 psig) air inlet pressure against 2 bar (30 psig) head pressure.

Example: To pump 167 lpm (44 gpm) against a discharge head of 2.1 bar (30 psig) requires 4.1 bar (60 psig) and 71 Nm³/h (45 scfm) air consumption.


Caution: Do not exceed 8.6 bar (125 psig) air supply pressure.



Flow rates indicated on chart were determined by pumping water.

For optimum life and performance, pumps should be specified so that daily operation parameters will fall in the center of the pump's performance curve.


P420/P430 METAL FULL-STROKE PTFE-FITTED



¹Displacement per stroke was calculated at 4.8 bar (70 psig) air inlet pressure against 2 bar (30 psig) head pressure.

Example: To pump 307 lpm (81 gpm) against a discharge head of 2.1 bar (30 psig) requires 5.5 bar (80 psig) and 96 Nm³/h (61 scfm) air consumption.

Caution: Do not exceed 8.6 bar (125 psig) air supply pressure.



Flow rates indicated on chart were determined by pumping water.

For optimum life and performance, pumps should be specified so that daily operation parameters will fall in the center of the pump's performance curve.






SUCTION-LIFT CURVES

P420/P430 METAL SUCTION-LIFT CAPABILITY

Suction-lift curves are calibrated for pumps operating at 305 m (1,000') above sea level. This chart is meant to be a guide only. There are many variables that can affect your pump's operating characteristics. The number of intake and discharge elbows, viscosity of pumping fluid, elevation (atmospheric pressure) and pipe friction loss all affect the amount of suction lift your pump will attain.





NOTES



SUGGESTED INSTALLATION

Wilden pumps are designed to meet the performance requirements of even the most demanding pumping applications. They have been designed and manufactured to the highest standards and are available in a variety of liquid path materials to meet your chemical resistance needs. Refer to the performance section of this manual for an in-depth analysis of the performance characteristics of your pump. Wilden offers the widest variety of elastomer options in the industry to satisfy temperature, chemical compatibility, abrasion resistance and flex concerns.

The suction pipe size should be at least the equivalent or larger than the diameter size of the suction inlet on your Wilden pump. The suction hose must be non-collapsible, reinforced type as these pumps are capable of pulling a high vacuum. Discharge piping should also be the equivalent or larger than the diameter of the pump discharge which will help reduce friction losses. It is critical that all fittings and connections are airtight or a reduction or loss of pump suction capability will result.

INSTALLATION: Months of careful planning, study and selection efforts can result in unsatisfactory pump performance if installation details are left to chance.

Premature failure and long-term dissatisfaction can be avoided if reasonable care is exercised throughout the installation process.

LOCATION: Noise, safety and other logistical factors usually dictate where equipment will be situated on the production floor. Multiple installations with conflicting requirements can result in congestion of utility areas, leaving few choices for additional pumps.

Within the framework of these and other existing conditions, every pump should be located in such a way that six key factors are balanced against each other to maximum advantage.

ACCESS: First of all, the location should be accessible. If it's easy to reach the pump, maintenance personnel will have an easier time carrying out routine inspections and adjustments. Should major repairs become necessary, ease of access can play a key role in speeding the repair process and reducing total downtime.

AIR SUPPLY: Every pump location should have an air line large enough to supply the volume of air necessary to achieve the desired pumping rate. Use air pressure up to a maximum of 8.6 bar (125 psig) depending on pumping requirements.

For best results, the pumps should use a 5μ (micron) air filter, needle valve and regulator. The use of an air filter before the pump will ensure that the majority of any pipeline contaminants will be eliminated.

SOLENOID OPERATION: When operation is controlled by a solenoid valve in the air line, three-way valves should be used. This valve allows trapped air between the valve and the pump to bleed off which improves pump performance. Pumping volume can be estimated by counting the number of strokes per minute and then multiplying the figure by the displacement per stroke.

MUFFLER: Sound levels are reduced below OSHA specifications using the standard Wilden muffler. Other mufflers can be used to further reduce sound levels, but they usually reduce pump performance.

ELEVATION: Selecting a site that is well within the pump's dynamic lift capability will assure that loss-of-prime issues will be eliminated. In addition, pump efficiency can be adversely affected if proper attention is not given to site location.

PIPING: Final determination of the pump site should not be made until the piping challenges of each possible location have been evaluated. The impact of current and future installations should be considered ahead of time to make sure that inadvertent restrictions are not created for any remaining sites.

The best choice possible will be a site involving the shortest and straightest hook-up of suction and discharge piping. Unnecessary elbows, bends and fittings should be avoided. Pipe sizes should be selected to keep friction losses within practical limits. All piping should be supported independently of the pump. In addition, the piping should be aligned to avoid placing stress on the pump fittings.

Flexible hose can be installed to aid in absorbing the forces created by the natural reciprocating action of the pump. If the pump is to be bolted down to a solid location, a mounting pad placed between the pump and the foundation will assist in minimizing pump vibration. Flexible connections between the pump and rigid piping will also assist in minimizing pump vibration. If quick-closing valves are installed at any point in the discharge system, or if pulsation within a system becomes a problem, a surge suppressor (SD Equalizer®) should be installed to protect the pump, piping and gauges from surges and water hammer.

If the pump is to be used in a self-priming application, make sure that all connections are airtight and that the suction lift is within the model's ability. **NOTE**: Materials of construction and elastomer material have an effect on suction-lift parameters. Please refer to the performance section for specifics.

When pumps are installed in applications involving flooded suction or suction head pressures, a gate valve should be installed in the suction line to permit closing of the line for pump service.

Pumps in service with a positive suction head are most efficient when inlet pressure is limited to 0.5–0.7 bar (7–10 psig). Premature diaphragm failure may occur if positive suction is 0.7 bar (10 psig) and higher.

NOT FOR SUBMERSIBLE APPLICATIONS: Pro-Flo® pumps cannot be used in submersible applications.


ALL WILDEN PUMPS ARE CAPABLE OF PASSING SOLIDS. A STRAINER SHOULD BE USED ON THE PUMP INTAKE TO ENSURE THAT THE PUMP'S RATED SOLIDS CAPACITY IS NOT EXCEEDED.

CAUTION: DO NOT EXCEED 8.6 BAR (125 PSIG) AIR SUPPLY PRESSURE.





SUGGESTED INSTALLATION



NOTE: In the event of a power failure, the shut-off valve should be closed, if the restarting of the pump is not desirable once power is regained.

AIR-OPERATED PUMPS: To stop the pump from operating in an emergency situation, simply close the shut-off valve (user-supplied) installed in the air supply line. A properly functioning valve will stop the air supply to the pump, therefore stopping output. This shut-off valve should be located far enough away from the pumping equipment such that it can be reached safely in an emergency situation.





SUGGESTED OPERATION & MAINTENANCE

OPERATION: The Pro-Flo® pumps are pre-lubricated and do not require in-line lubrication. Additional lubrication will not damage the pump; however if the pump is heavily lubricated by an external source, the pump's internal lubrication may be washed away. If the pump is then moved to a non-lubricated location, it may need to be disassembled and re-lubricated as described in the DISASSEMBLY/REASSEMBLY INSTRUCTIONS.

Pump discharge rate can be controlled by limiting the volume and/or pressure of the air supply to the pump. An air regulator is used to regulate air pressure. A needle valve is used to regulate volume. Pump discharge rate can also be controlled by throttling the pump discharge by partially closing a valve in the discharge line of the pump. This action increases friction loss which reduces flow rate. (See Section 5.) This is useful when the need exists to control the pump from a remote location. When the pump discharge pressure equals or exceeds the air supply pressure, the pump will stop; no bypass or pressure relief valve is needed, and pump damage will not occur. The pump has reached a "deadhead" situation and can be restarted by reducing the fluid discharge

pressure or increasing the air inlet pressure. Wilden Pro-Flo® pumps run solely on compressed air and do not generate heat; therefore, your process fluid temperature will not be affected.

MAINTENANCE AND INSPECTIONS: Since each application is unique, maintenance schedules may be different for every pump. Frequency of use, line pressure, viscosity and abrasiveness of process fluid all affect the parts life of a Wilden pump. Periodic inspections have been found to offer the best means for preventing unscheduled pump downtime. Personnel familiar with the pump's construction and service should be informed of any abnormalities that are detected during operation.

RECORDS: When service is required, a record should be made of all necessary repairs and replacements. Over a period of time, such records can become a valuable tool for predicting and preventing future maintenance problems and unscheduled downtime. In addition, accurate records make it possible to identify pumps that are poorly suited to their applications.

TROUBLESHOOTING

Pump will not run or runs slowly.

- Ensure that the air inlet pressure is at least 0.4 bar (5 psig) above startup pressure and that the differential pressure (the difference between air inlet and liquid discharge pressures) is not less than 0.7 bar (10 psig).
- 2. Check air inlet filter for debris (see SUGGESTED INSTALLATION).
- 3. Check for extreme air leakage (blow by) that would indicate worn seals/bores in the air valve, pilot spool and main shaft.
- 4. Disassemble pump and check for obstructions in the air passageways or objects that would obstruct the movement of internal parts.
- 5. Check for sticking ball check valves. If material being pumped is not compatible with pump elastomers, swelling may occur. Replace ball check valves and seals with proper elastomers. Also, as the check valve balls wear out, they become smaller and can become stuck in the seats. In this case, replace balls and seats.
- 6. Check for broken inner piston that would cause the air valve spool to be unable to shift.
- 7. Remove plug from pilot spool exhaust.

Pump runs but little or no product flows.

1. Check for pump cavitation; slow pump speed down to allow thick material to flow into liquid chambers.

- 2. Verify that vacuum required to lift liquid is not greater than the vapor pressure of the material being pumped (cavitation).
- 3. Check for sticking ball check valves. If material being pumped is not compatible with pump elastomers, swelling may occur. Replace ball check valves and seats with proper elastomers. Also, as the check valve balls wear out, they become smaller and can become stuck in the seats. In this case, replace balls and seats.

Pump air valve freezes.

 Check for excessive moisture in compressed air. Either install a dryer or hot air generator for compressed air. Alternatively, a coalescing filter may be used to remove the water from the compressed air in some applications.

Air bubbles in pump discharge.

- 1. Check for ruptured diaphragm.
- 2. Check tightness of outer pistons (refer to Section 7).
- 3. Check tightness of fasteners and integrity of O-rings and seals, especially at intake manifold.
- 4. Ensure pipe connections are airtight.

Product comes out air exhaust.

- 1. Check for diaphragm rupture.
- 2. Check tightness of outer pistons to shaft.




PUMP DISASSEMBLY

Tools Required

- 9/16" Socket Wrench
- 1" Socket Wrench (Rubber-Fitted)
- 23 mm Socket Wrench (PTFE-Fitted)
- Snap-Ring Pliers
- Vise equipped w/ soft jaws (such as plywood, plastic or other suitable material)


CAUTION: Before any maintenance or repair is attempted, the compressed air line to the pump should be disconnected and all air pressure allowed to bleed from the pump. Disconnect all intake, discharge and air lines. Drain the pump by turning it upside down and allowing any fluid to flow into a suitable container. Be aware of any hazardous effects of contact with your process fluid.

NOTE: The model photographed is an aluminum PX820 51 mm (2") pump. Your specific pump model may vary from the configuration shown; however, pump disassembly procedure will be the same.



Step 1

Before starting disassembly, mark a line from each liquid chamber to its corresponding air chamber. This line will assist in proper alignment during reassembly.



Step 2

Using the appropriate-sized wrench for your pump size, loosen the discharge manifold from the liquid chambers.




Step 3

Lift the discharge manifold to expose discharge valve balls and valve seats. Inspect ball cage area of manifold for excessive wear or damage.




PUMP DISASSEMBLY



Step 4

Remove the discharge valve balls and valve seats from the liquid chambers and inspect for nicks, gouges, chemical attack or abrasive wear. Replace worn parts with genuine Wilden parts for reliable performance.




Step 5

Using the appropriate-sized wrench, loosen the inlet manifold from the liquid chambers. **NOTE**: Inverting the pump will facilitate removal of inlet manifold.



Step 6

Remove the inlet manifold to expose the valve balls and valve seats.



Step 7

Remove the inlet valve balls and valve seats from the inlet manifold and liquid chambers and inspect for nicks, gouges, chemical attack or abrasive wear.

NOTE: Replace worn parts with genuine Wilden parts for reliable performance.



Step 8

Using the appropriate-sized wrench, remove the liquid chamber from the center section.



Step 9

The liquid chamber should be removed to expose the diaphragm and outer piston using an adjustable wrench. Remove the diaphragm assembly from the center section. Repeat for opposite side.





PUMP DISASSEMBLY



Step 10

After loosening and removing the outer piston, the diaphragm assembly can be disassembled.



Step 11

To remove diaphragm assembly from shaft, secure shaft with soft jaws (a vise fitted with plywood, plastic or other suitable material) to ensure shaft is not nicked, scratched or gouged. Using an adjustable wrench, remove diaphragm assembly form shaft.



AIR VALVE / CENTER SECTION DISASSEMBLY

Tools Required:

- 3/16" Hex-Head Wrench
- Snap-Ring Pliers
- O-Ring Pick

CAUTION: Before any maintenance or repair is attempted, the compressed air line to the pump should be disconnected and all air pressure allowed to bleed from the pump. Disconnect all intake, discharge and air lines. Drain the pump by turning it upside down and allowing any fluid to flow into a suitable container. Be aware of hazardous effects of contact with your process fluid.

The Wilden P420 and P430 metal pumps utilize a revolutionary Pro-Flo® air distribution system. Proprietary composite seals reduce the coefficient of friction and allow the pumps to run lube-free. The Pro-Flo® air distribution system is designed to perform in on/off, non-freezing, non-stalling, tough-duty applications.



Step 1

Using a 3/16" Hex wrench, loosen air valve bolts.



Step 2

Remove muffler plate and air valve bolts from air valve assembly exposing muffler gasket for inspection. Replace if necessary.



Step 3

Lift away air valve assembly and remove air valve gasket for inspection. Replace if necessary.

AIR VALVE / CENTER SECTION DISASSEMBLY



Step 4

Remove air valve end cap to expose air valve spool by simply lifting up on end cap once air valve bolts are removed. Note: Pro-Flo X^{TM} air valve incorporates an end cap at both ends of the air valve.



Step 5

Remove the air valve spool from the air valve body by threading one air valve bolt into the end of the air valve spool and gently sliding the spool out of the air valve body. Inspect seals for signs of wear and replace entire assembly if necessary. Use caution when handling air valve spool to prevent damaging seals. Note: Seals should not be removed from assembly. Seals are not sold separately.



Step 6

Remove pilot sleeve retaining snap ring on both sides of center section with snap ring pliers.



Step 7

Remove pilot spool sleeve from center section.



Step 8



Using an o-ring pick, gently remove the o-ring from the opposite side of the "notched end" on one side of the pilot spool. Gently remove the pilot spool from pilot spool sleeve and inspect for nick, gouges and wear. Replace pilot sleeve or outer sleeve o-rings if necessary. During re-assembly, never insert the pilot spool into the sleeve with the "notched end" first, this end incorporates the urethane o-ring and will be damaged as it slides over the ports cut in the sleeve. Note: Seals should not be removed from pilot spool. Seals are not sold separately.





AIR VALVE / CENTER SECTION DISASSEMBLY



Step 9

Check center section seals for signs of wear. If necessary, remove seals with o-ring pick and replace.





REASSEMBLY HINTS & TIPS

REASSEMBLY:


Upon performing applicable maintenance to the air distribution system, the pump can now be reassembled. Please refer to the disassembly instructions for photos and parts placement. To reassemble the pump, follow the disassembly instructions in reverse order. The air distribution system needs to be assembled first, then the diaphragms and finally the wetted path. Please find the applicable torque specifications on this page. The following tips will assist in the assembly process.

- Lubricate air valve bore, center section shaft and pilot spool bore with NLGI grade 2 white EP bearing grease or equivalent.
- Clean the inside of the center section shaft bore to ensure no damage is done to new shaft seals.
- A small amount of NLGI grade 2 white EP bearing grease can be applied to the muffler and air valve gaskets to lubricate gaskets during assembly.
- Make sure that the exhaust port on the muffler plate is centered between the two exhaust ports on the center section.
- Stainless bolts should be lubed to reduce the possibility of seizing during tightening.

PRO-FLO® MAXIMUM TORQUE SPECIFICATIONS

Description of Part	Torque
Air Valve	5.1 N•m (45 in-lb)
Air Chamber/Center Block	27.1 N•m (20 ft-lb)
Liquid Chamber/Air Chamber, Aluminum Bolted Only	47.5 N•m (35 ft-lb)
Liquid Chamber/Air Chamber, Stainless Steel Bolted Only	17.6 N•m (13 ft-lb)
Liquid Chamber to Air Chamber, Aluminum	54.2 N•m (40 ft-lb)

Figure A



SHAFT SEAL INSTALLATION:

PRE-INSTALLATION


 Once all of the old seals have been removed, the inside of the bushing should be cleaned to ensure no debris is left that may cause premature damage to the new seals.

INSTALLATION

The following tools can be used to aid in the installation of the new seals:

Needle-Nose Pliers Phillips Screwdriver Electrical Tape

- Wrap electrical tape around each leg of the needle-nose pliers (heat shrink tubing may also be used). This is done to prevent damaging the inside surface of the new seal.
- With a new seal in hand, place the two legs of the needle-nose pliers inside the seal ring. (See Figure A.)
- Open the pliers as wide as the seal diameter will allow, then with two fingers pull down on the top portion of the seal to a kidney shape. (See Figure B.)
- Lightly clamp the pliers together to hold the seal into the kidney shape. Be sure to pull the seal into as tight of a kidney shape as possible, this will allow the seal to travel down the bushing bore with greater ease.
- With the seal clamped in the pliers, insert the seal into the bushing bore and position the bottom of the seal into the correct groove. Once the bottom of the seal is seated in the groove, release the clamp pressure on the pliers. This will allow the seal to partially snap back to its original shape.
- After the pliers are removed, you will notice a slight bump in the seal shape. Before the seal can be properly resized, the bump in the seal should be removed as much as possible. This can be done with either the Phillips screwdriver or your finger. With either the side of the screwdriver or your finger, apply light pressure to the peak of the bump. This pressure will cause the bump to be almost completely eliminated.
- Lubricate the edge of the shaft with NLGI grade 2 white EP bearing grease.
- Slowly insert the center shaft with a rotating motion. This will complete the resizing of the seal.
- Perform these steps for the remaining seals.




PROFILO®

EXPLODED VIEW & PARTS LISTING

P420/P430 METAL

EXPLODED VIEW



ALL CIRCLED PART IDENTIFIERS ARE INCLUDED IN REPAIR KITS

LW0379 REV. C





EXPLODED VIEW & PARTS LISTING

P420/P430 METAL

PARTS LISTING

Item	Description	Qty.	P420/430/ AAAPP//P/N	P420/430/ SSAPP//P/N	P420/430/ WMAPP//P/N	
AIR DISTRIBUTION COMPONENTS						
1	Air Valve Assembly, Pro-Flo®1	1	04-2000-20-700	04-2000-20-700	04-2000-20-700	
2	O-Ring, End Cap (-225, Ø1.859" x Ø.139")	1	04-2390-52-700	04-2390-52-700	04-2390-52-700	
3	End Cap, Pro-Flo®	1	04-2330-20-700	04-2330-20-700	04-2330-20-700	
4	Screw, SHC, Air Valve (1/4"-20 x 4-1/2")	4	01-6000-03	01-6000-03	01-6000-03	
5	Screw, Self Tapping, SHC (10-16 x 1-3/4")	2	04-6351-03	04-6351-03	04-6351-03	
6	Nut, Square (1/4"-20)	4	00-6505-03	00-6505-03	00-6505-03	
7	Muffler Plate, Pro-Flo®	1	04-3180-20-700	04-3180-20-700	04-3180-20-700	
8	Gasket, Muffler Plate, Pro-Flo®	1	04-3500-52-700	04-3500-52-700	04-3500-52-700	
9	Gasket, Air Valve, Pro-Flo®	1	04-2600-52-700	04-2600-52-700	04-2600-52-700	
10	Center Block Assembly, Pro-Flo® 2	1	04-3110-20	04-3110-20	04-3110-20	
11	Sleeve, Threaded, Center Block	4	04-7710-08	04-7710-08	04-7710-08	
12	Pilot Sleeve Assembly	1	04-3880-99	04-3880-99	04-3880-99	
13	O-Ring, Pilot Spool Retaining (-009, Ø.208" x Ø.070")	2	04-2650-49-700	04-2650-49-700	04-2650-49-700	
14	Seal, Shaft	2	08-3210-55-225	08-3210-55-225	08-3210-55-225	
15	Gasket, Center Block Pro-Flo®	2	04-3526-56	04-3526-56	04-3526-56	
16	Air Chamber, Advanced FIT Pro-Flo®	2	04-3681-01	04-3681-01	04-3681-01	
17	Screw, HSFHS (3/8"-16 x 1")	8	71-6250-08	71-6250-08	71-6250-08	
18	Retaining Ring	2	04-3890-03	04-3890-03	04-3890-03	
19	Bushing, Reducer 3/4" MNPT to 1/2" FNPT	1	04-6950-20-700	04-6950-20-700	04-6950-20-700	
20	Muffler 3/4" MNPT	1	04-3510-99	04-3510-99	04-3510-99	
	WETTED PATH C	Т			T	
21	Liquid Chamber	2	04-5015-01	04-5015-03	04-5015-02	
22	Manifold, Discharge, 1-1/2" (NPT)	1	04-5035-01	04-5035-03	04-5035-02	
	Manifold, Discharge, 1-1/2" (BSPT)	1	04-5036-01	04-5036-03	04-5036-02	
	Manifold, Discharge, Vert 1-1/4" (NPT)	1	04-5037-01	04-5037-03	04-5037-02	
	Manifold, Discharge, Vert 1-1/4" (BSPT)	1	04-5038-01	04-5038-03	04-5038-02	
	Manifold, Discharge, 1-1/2" (ANSI)	1	04-5045-01	04-5045-03	04-5045-02	
	Manifold, Discharge, 1-1/2" (DIN)	1	04-5046-01	04-5046-03	04-5046-02	
23	Square Pipe Plug 1-1/2" (NPT)	1	04-7010-01	04-7010-03	04-7010-08	
	Square Pipe Plug 1-1/2" (BSPT)	1	04-7011-01	04-7011-03	04-7011-08	
24	Manifold, Inlet, 1-1/2" (NPT)	1	04-5095-01	04-5095-03	04-5095-02	
	Manifold, Inlet, 1-1/2" (BSPT)	1	04-5096-01	04-5096-03	04-5096-02	
	Manifold, Inlet, 1-1/2" (ANSI)	1	04-5125-01	04-5125-03	04-5125-02	
	Manifold, Inlet, 1-1/2" (DIN)	1	04-5126-01	04-5126-03	04-5126-02	
25	Screw, HHC (3/8"-16 x 1")	16	08-6130-08	08-6130-03	08-6130-08	
26	Screw, HHC (3/8"-16 x 1-1/4")	16	04-6140-08	04-6190-03	04-6140-08	
27	Washer, Flat, (Ø.406" x Ø.812" x .065")	32	15-6740-08-50	04-6740-03	15-6740-08-50	
	VALVE BALLS/VALVE SE	ATS/V	ALVE O-RINGS			
28	Ball, Valve	4	*	*	*	
29	Seat, Valve	4	*	*	*	
30	Valve Seat O-Ring, PTFE-Fitted (-338, Ø3.100" x Ø.210") (not shown)	4	71-1281-55	71-1281-55	71-1281-55	
	FULL-STROKE RUBBER/TI	PE/PTF	FE/COMPONENTS			
31	Shaft	1	04-3800-03-700	04-3800-03-700	04-3800-03-700	
32	Shaft Stud 1/2"-20 x 1-7/8"	2	08-6150-08	08-6150-08	N/A	
33	Piston, Inner	2	04-3700-01-700	04-3700-01-700	04-3700-01-700	
34	Diaphragm, Primary	2	*	*	*	
	Diaphragm, Backup	2	*	*	*	
35	Piston, Outer	2	04-4552-01	04-4550-03	04-4550-08	
36	Washer, Reinforcing, (Ø.531" x Ø2.188" x .194") (not shown)	2	N/A	N/A	04-6800-08	
37	Screw, HHC (1/2"-20 x 1-1/2") (not shown)	2	N/A	N/A	04-6091-08	
38	Screw, HHC (1/2"-20 x 1-1/2") (not shown)	2	N/A	N/A	04-6091-08	
	REDUCED-STROKE P					
31	Shaft, Reduced-Stroke PTFE	1	04-3820-03-700	04-3820-03-700	04-3820-03-700	
32	Shaft Stud 1/2"-20 x 1-7/8"	2	08-6150-08	08-6150-08	08-6150-08	
33	Piston, Inner, Reduced-Stroke PTFE	2	04-3752-01	04-3752-01	04-3752-01	
34	Diaphragm, Primary, Reduced-Stroke PTFE	2	04-1010-55-42	04-3752-01	04-3752-01	
35	Diaphragm, Backup, Reduced-Stroke PTFE	2	*	*	*	
36	Piston, Outer, Reduced-Stroke PTFE	2	04-4600-01	04-4600-03	04-4600-03	
50	r istori, outer, neutroeu-outoke l'II L	1 4	I 0-4000-40	UT-TUUU-UJ	11//0200 DEV	

^{*}See elastomer chart -Section 9

All boldface items are primary wear parts.

¹Air Valve Assembly includes items 2 and 3.

² Plastic Center Block Assembly includes items 6, 11, 12, 14 and 19.





ELASTOMER OPTIONS

P420/P430 Metal

MATERIAL	DIAPHRAGMS (2)	REDUCED- STROKE BACKUP DIAPHRAGMS (2)	FULL-STROKE DIAPHRAGMS (2)	FULL-STROKE BACKUP DIAPHRAGMS (2)	EZ-INSTALL Diaphragms (2)	VALVE BALLS (4)	VALVE SEATS (4)	VALVE SEAT O-RINGS (4)
Polyurethane	N/A	N/A	N/A	N/A	04-1022-50	08-1080-62-50	04-1128-50	N/A
Neoprene	04-1010-51	04-1060-51	N/A	N/A	N/A	08-1080-51-50	04-1128-51	N/A
Buna-N®	04-1010-52	N/A	N/A	N/A	N/A	08-1080-52-50	04-1128-52	N/A
FDA Buna-N®	04-1010-69	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Conductive Buna-N®	04-1010-86	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Geolast	N/A	N/A	N/A	N/A	04-1022-15	N/A	N/A	N/A
EPDM	04-1010-54	04-1060-54	N/A	N/A	N/A	08-1080-54-50	04-1128-54	N/A
FDA EPDM	04-1010-74	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Viton®	04-1010-53	N/A	N/A	N/A	N/A	08-1080-53-50	04-1128-53	N/A
PTFE	04-1010-55-42	N/A	04-1040-55-42	N/A	N/A	04-1085-55	N/A	71-1281-55 ¹
Saniflex™	N/A	04-1060-56	N/A	04-1065-56	04-1022-56	08-1080-56-50	04-1128-56	N/A
FDA Wil-Flex™	N/A	N/A	N/A	04-1065-57	04-1022-57	N/A	04-1128-57	N/A
Wil-Flex™	N/A	N/A	N/A	N/A	04-1022-58	08-1080-58-50	04-1128-58	N/A
Aluminum	N/A	N/A	N/A	N/A	N/A	N/A	04-1129-01	N/A
Mild Steel	N/A	N/A	N/A	N/A	N/A	N/A	04-1129-08	N/A
Stainless Steel	N/A	N/A	N/A	N/A	N/A	N/A	04-1129-03	N/A

¹Used in conjunction with metallic valve seat.

LW0380 REV. C



NOTES



NOTES



WARRANTY

Each and every product manufactured by Wilden Pump and Engineering, LLC is built to meet the highest standards of quality. Every pump is functionally tested to insure integrity of operation.

Wilden Pump and Engineering, LLC warrants that pumps, accessories and parts manufactured or supplied by it to be free from defects in material and workmanship for a period of five (5) years from date of installation or six (6) years from date of manufacture, whichever comes first. Failure due to normal wear, misapplication, or abuse is, of course, excluded from this warranty.

Since the use of Wilden pumps and parts is beyond our control, we cannot guarantee the suitability of any pump or part for a particular application and Wilden Pump and Engineering, LLC shall not be liable for any consequential damage or expense arising from the use or misuse of its products on any application. Responsibility is limited solely to replacement or repair of defective Wilden pumps and parts.

All decisions as to the cause of failure are the sole determination of Wilden Pump and Engineering, LLC.

Prior approval must be obtained from Wilden for return of any items for warranty consideration and must be accompanied by the appropriate MSDS for the product(s) involved. A Return Goods Tag, obtained from an authorized Wilden distributor, must be included with the items which must be shipped freight prepaid.

The foregoing warranty is exclusive and in lieu of all other warranties expressed or implied (whether written or oral) including all implied warranties of merchantability and fitness for any particular purpose. No distributor or other person is authorized to assume any liability or obligation for Wilden Pump and Engineering, LLC other than expressly provided herein.

PLEASE PRINT OR TYPE AND FAX TO WILDEN

PUMP INFORMATION			
Item #	Serial #		
Company Where Purchased			
YOUR INFORMATION			
Company Name			
Industry			
Name		Title	
Street Address			
City	State	Postal Code	Country
Telephone Fax E	E-mail		Web Address
Number of pumps in facility?	_ Number of W	/ilden pumps?	
Types of pumps in facility (check all that apply): Diaphragm	n Centrifu	ugal 🗌 Gear	Submersible Lobe
Other			
Media being pumped?			
How did you hear of Wilden Pump?	Trade Show	w Interr	net/E-mail Distributor
Other			

ONCE COMPLETE, FAX TO (909) 783-3440





Where Innovation Flows

WILDEN®

PSG 22069 Van Buren St., Grand Terrace, CA 92313-5607 P: +1 (909) 422-1730 • F: +1 (909) 783-3440 wildenpump.com PSG' reserves the right to modify the information and illustrations contained in this document without prior notice. This is a non-contractual document. 07-2018

Authorized PSG Representative:

airpumping.co.uk

Copyright ©2018, PSG*, A Dover Company